



IRIS™

THE FLORAL-INSPIRED
VIBRATOR WITH
SCULPTED RIDGES

PRODUCT DESCRIPTION

IRIS™ uses a powerful vibrating motor in the tip and another in the base to offer twice the intensity, while the sensual, flowing, petal-like ridges transmit those vibrations luxuriantly into your body.

- **Petal design for rippling pleasure**
The stylish, rolling shape of IRIS™ adds surface area to its body, stimulating more of your sensitive nerve endings
- **Power & elegance for a satisfying climax**
Two perfectly placed motors and a gently curved body make IRIS™ irresistible externally and internally
- **Surging vibrations for discerning women**
This massager feels different from everything else because the petal-like ridges add a surging sensation to the vibrations

SPECIFICATIONS

- **Materials:** ABS Plastic / Silicone
- **Finish:** Matte
- **Size:** 220 x 42 x 36mm / 8.7 x 1.7 x 1.4in.
- **Diameter:** ø 39mm / 1.5in.
- **Insertable Length:** 130mm / 5.1in.
- **Weight:** 170g / 6.0oz
- **Battery:** Li-Ion 920mAh 3.7V
- **Charging:** 2hrs at 5.0V 500mA
- **User Time:** Up to 4hrs
- **Standby:** Up to 90 days
- **Frequency:** 120Hz
- **Max Noise Level:** <50dB
- **Interface:** Variable interface dial, 5 modes

FEATURES

Unique petal-ridged design for more intense sensations

Smooth body-safe silicone design

Control over two powerful motors in base and tip, with 5 vibration patterns



LELO

L 220mm/8.66"

Ø 42mm/1.65"


CONTROLS



- Press + to turn on and to increase vibration strength.
- Press - to lower vibration strength; hold - to turn off.
- Press ▲ and ▼ to cycle through the different vibration patterns.
- Lock by holding + and - for 5 seconds; the light will turn off when the device is locked.
- Unlock by pressing for 5 more seconds; the light will turn on when the device is active.

CHARGING

Always charge LELO massagers before first use and only use original chargers provided by LELO



Insert the LELO
charger into the
charging socket

The light will pulsate
to indicate that your
massager is charging

When fully charged,
the light will emit a
steady glow

LELO

HYGIENE & CARE



Use **LELO's Antibacterial Cleaning Spray** before and after each use for total peace of mind.

When cleaning with water, **ALWAYS** use a premium antibacterial solution. This product is not waterproof.

Take care not to get water in the control interface or charging socket.

Store your LELO massager in its protective storage pouch between uses.

WARNING: Do not boil or use metal scour. Avoid leaving your LELO in direct sunlight and **NEVER** expose it to extreme heat. Do not use on swollen or damaged skin. Keep your LELO out of the reach of children.

IMPORTANT: For Adult Use Only. Those who may be pregnant, have a pacemaker, diabetes, phlebitis or thrombosis should consult with a medical professional regarding the risk of blood clots before using any personal massage product.



LELO

WARRANTY REGISTRATION

1. Visit **LELO.com** and click **REGISTER/LOG IN** in the top right corner of the screen.
2. Follow the directions to register your product and attach details of your purchase.

Don't forget to take advantage of
LELO's full warranty coverage.



The serial number is on the back of the authenticity card provided with every LELO product.

LELO

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems).

The crossed-out dustbin symbol indicates that this product should not be treated as household waste, but rather be brought to the appropriate collection point for recycling of electrical and electronic equipment.



* FCC Mark, C-Tick and IC certifications relevant to remote-controlled products only.

Disclaimer: Users of this LELO Product do so at their own risk. Neither LELO nor its retailers assume any responsibility or liability for the use of this product. Further, LELO reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Applicable for ALL products. Model may be changed for improvements without notice.

© 2015 LELoi AB. ALL RIGHTS RESERVED.

LELOi AB, Birger Jarlsgatan 22, 114 34 STOCKHOLM, SWEDEN.

LELO Inc., 4320 STEVENS CREEK BLVD., SUITE #205, SAN JOSE, CA 95129, USA.

DESIGNED AND DEVELOPED BY LELO SWEDEN

MANUFACTURED BY LELO IN CHINA

WEBSITE WWW.LELO.COM - SUPPORT CUSTOMERCARE@LELO.COM

LELO

LELO